

**Procedure to Ready Procurement Centre Computer to Use Bio-Metric Device for Aadhar Enabled Bio-Metric Authentication of Farmer/Nominee at the time of Sale.**

- 1) Make sure that you are using IDEMIA (Morpho) Model MPH-SE005C finger print reading device and Mantra MIS 100V2 single iris sensor devices for bio-metric authentication of the Farmer/Nominee.
- 2) **IDEMIA (Morpho) Model MPH-SE005C finger print related:** Install RD service and Device Drivers by downloading files from <https://rdserviceonline.com/>. On visiting this URL, you will get a prompt titled "Attention" and having two links. Use the option "*for Windows Click Here*". A zip file "WindowsRDSserviceV2.0.1.60-HTTP" will be downloaded in the download folder. Unzip the file to get executable "WindowsRDSservice-HTTP.exe". Run this exe to install device driver and RD service.
- 3) **Mantra MIS 100V2 single iris sensor related:**

Visit the URL <https://download.mantratecapp.com/forms/downloadfiles>. You will be asked to enter captcha. You will get page with multiple tabs for various devices.

  - a) **Install Device Driver:** Download device driver by clicking the link "[Download MIS100V2 Driver \(2.1.0.0\) - Win 7/8/10](#)" under the tab "WINDOWS Download MIS100V2 Driver". Install the driver by executing the EXE downloaded from this link.
  - b) **Install RD Service:** Download RD service by clicking the link "[Download Mantra MIS100V2 RD Service \(1.0.4\)](#)" under "WINDOWS Download MIS100V2 RD Service". Install the RD service by executing the EXE downloaded from this link.